(1)

Set Defaults

Scanning this bar code sets all parameters to their default values.

SET DEFAULTS

(2)

Do Not Transmit UPC-A Check Digit

(3)

**Convert UPC-E to UPC-A
(Enable)**

(4)

Do Not Transmit UPC-E Check Digit

(5)

**No Preamble
(<DATA>)**

(6)

**No Preamble
(<DATA>)**

Symbol

(7)

BEGIN NEW RULE

(8)

SEND [

(9)

**SEND ALL DATA THAT
REMAINS**

(10)

SEND]

(11)

SAVE RULE